# FOCAL/RENAULT DACIA

INSTALLATION OF LIVE / PREMIUM RENAULT DACIA Lodgy- July 2017




1


### RECOMMENDATIONS BEFORE INSTALLATION

- Reset all car radio audio settings:
  - Ambience = Natural
  - Bass / Midrange / Treble settings = 0
  - Loudness = OFF
  - Fader and Balance = Centred
- The speaker drivers require a break-in period (approximately 20 hours) before they reach optimal sound quality.
  - After this break-in period, you can fine-tune the audio settings as you please.














IFR 165-4














### II. ASSEMBLING THE FRONT SPEAKER DRIVERS

### 1. Equipment required for assembling the woofer





### II. ASSEMBLING THE FRONT SPEAKER DRIVERS

#### 2. Connections

Note:

the crossover (with the black shielding) can be mounted any way around.



Speaker driver

Crossover







Fasten the crossover in place using a cable tie.

Note:

the cable tie mustn't come into contact with the spider (yellow part) when the speaker driver is in motion.



### III. INSTALLING THE FRONT SPEAKER DRIVERS

The picture below shows the location of the screws to remove.



1. Unclip the panel to remove the screw then remove the console and unclip the connectics









## III. INSTALLING THE FRONT SPEAKER DRIVERS

### 2. Remove the panel using the prying tool





### III. INSTALLING THE FRONT SPEAKER DRIVERS

3. Remove the original speaker by piercing the rivets





4. Rivet and connect the Focal speaker





### IV. ASSEMBLING THE TWEETERS

1. Equipment required for assembling the tweeter.


2. Remove the grille by simply unclipping it.



Support

Installation key






### IV. ASSEMBLING THE TWEETERS

### 3. Connect at position 1

Note:

Position 2 is not used in this set-up.





### Wiring required for the tweeter connection





#### Note:

Be careful to apply the correct fitting orientation (right/left) during the wiring installation in the vehicle.



### 1.a Remove the panels behind the steering wheel then the dashbord sunvisor







### 1.b Remove the central console and unscrew the screws











2. Remove the headunit and disconnect the right plug to the focal beam. Then connect the Focal beam to the










### 3. Connect the Focal beam to the tweeter cables





1.a Passenger Side: Run the right tweeter cable (grey) by the centrale console, run it over the glove box and then pull it out through the dashboard.

1.b Driver side: Run the left tweeter cable (white) by the center console, run it over the car speed meter and then exit it through the dashboard.










## 1. Remove the joint and the trim







2. Glue the template (see pages 14 & 15) on the basis of the trim and mark the holes locations for the screws









### 3. Drill the trim and fix the support







**4. Place the tweeter,** use the key to fix it with a quarter turn counterclockwise **and push the grille back** 







#### 5. Push the trim back







support

### VIII. ASSEMBLING THE REAR SPEAKER DRIVERS

The picture below shows the location of the screws to remove.



## 1. Remove the console and disconnect the connectic







### VIII. ASSEMBLING THE REAR SPEAKER DRIVERS

2. Remove the door panel using the prying tool



3. Pass the handle through the door panel





### VIII. ASSEMBLING THE REAR SPEAKER DRIVERS

4. Remove the original speaker piercing by the rivets






5. Screw the Focal speaker and orientate the tweeter upwards





### IX. PREPARING THE SUBWOOFER

### Equipment required for installing the subwoofer:




Ibus 2.1












Connectors




### IX. PREPARING THE SUBWOOFER

## 1. Glue the two strips of hook-and-loop fasteners as shown.

Note:


be careful not to cover up the serial number.







the adapter can only be used on an original head unit



3. Cut off the terminal and splice.




### X. POSITIONING AND ADJUSTING THE SUBWOOFER

### 1. Position the subwoofer under the passenger seat







Auto Power = ONPhase =  $180^{\circ}$ 

Phase = 180, this depends on many parameters, so it advisable to try both positions without altering any other settings, and then to choose the one which sounds best.



### X. POSITIONING AND ADJUSTING THE SUBWOOFER

2. Connect the power cable (red), the speakers beam and the ground cable (black)









1. Unclip the gear stick panel and remove the screw of the parking brake panel. Then disconnect the button.





2. Run the power cable (red), ground (black), speaker cable and remote control cable from the bottom of the seat to the underside of the handbrake bracket under the carpet. Then connect the ground cable to the screw











3. Pass the cable underneath the carpet along the center console and then pull the cable up to the radio





### 4. Plug the the extension cable to the connector






5. Run the cable from the remote control of the box control along the center console and then pass it over the glove compartment. Then, position the remote control.





6. Connect the power adapter to the power supply cable of the subwoofer and to the 12v socket located behind the parking brake

































FOCAL® is trademark of FOCAL-JMLAB®



