FOCAL/RENAULT

INSTALLATION OF LIVE / PREMIUM KITS FOR RENAULT Sandero II – January 2017




1




RECOMMENDATIONS BEFORE INSTALLATION


- Reset all car radio audio settings:
 - Ambience = Natural
 - Bass / Midrange / Treble settings = 0
 - Loudness = OFF
 - Fader and Balance = Centred
- The speaker drivers require a break-in period (approximately 20 hours) before they reach optimal sound quality.
 - After this break-in period, you can fine-tune the audio settings as you please.















IFRA130-4










II. ASSEMBLING THE FRONT SPEAKER DRIVERS

1. Equipment required for assembling the woofer





II. ASSEMBLING THE FRONT SPEAKER DRIVERS

2. Connections

Note:

the crossover (with the black shielding) can be mounted any way around.



Speaker driver

Crossover







Fasten the crossover in place using a cable tie.

Note:

the cable tie mustn't come into contact with the spider (yellow part) when the speaker driver is in motion.



III. INSTALLING THE FRONT SPEAKER DRIVERS

The picture below shows the location of the screws to remove.



Note:
To carefully remove



1. Unclip the door panels using prying tools. (clip to remove before removing the rear-view mirror gusset)







III. INSTALLING THE FRONT SPEAKER DRIVERS

2. Remove the original speaker driver





3. Rivet and connect the speaker driver





IV. ASSEMBLING THE TWEETERS

1. Equipment required for assembling the tweeter.


2. Remove the grille by simply unclipping it.



Support

Installation key






IV. ASSEMBLING THE TWEETERS

3. Connect at position 1

Note:

Position 2 is not used in this set-up.






V. INSTALLING THE TWEETERS


1. Remove the trim




2. Glue the template (see pages 15 & 16) on the basis of the trim and mark the holes locations for the screws









V. INSTALLING THE TWEETERS

3. Drill the trim and fix the support









V. INSTALLING THE TWEETERS

4. Place the tweeter, use the key to fix it with a quarter turn counterclockwise **and push the grille back**









5. Push the trim back





Installation key

1. Wiring required for the tweeter connection





Note:

Be careful to apply the correct fitting orientation (right/left) during the wiring installation in the vehicle.



2. Remove the head unit











3. On the driver's side: Remove the upper trim of the dashboard












4. Use a cable grommet to run the cable behind the dashboard then get it out through the windshield pillar











5. On the passenger's side: Use a cable grommet to run the cable behind the glove box (without disassembling) then get it out through the windshield pillar









6. Then connect the tweeters behind the head unit using the provided wiring







VII. ASSEMBLING THE REAR SPEAKER DRIVERS









VIII. INSTALLING THE REAR SPEAKER DRIVERS

The picture below shows the location of the screws to remove.



1. Unclip the door panels using prying tools.



VIII. INSTALLING THE REAR SPEAKER DRIVERS

2. Remove the original speaker driver.






3. Screw and connect the Focal speaker driver then tilt the rotating tweeter upwards.






IX. PREPARING THE SUBWOOFER

Equipment required for installing the subwoofer:




Ibus 2.1















IX. PREPARING THE SUBWOOFER

1. Glue the two strips of hook-and-loop fasteners as shown.

Note:


be careful not to cover up the serial number.



2. Connect the extension cable to the head unit subwoofer interconnect cable.



the adapter can only be used on an original head unit



3. Cut off the terminal and splice.



X. POSITIONING AND ADJUSTING THE SUBWOOFER

Position 1



Into the trunk.






Position 2



Under the left seat.





Phase: 0 or 180, this depends on many parameters, so it advisable to try both positions without altering any other settings, and then to choose the one which sounds best.



- 1. Remove the center console
- 1.a. The picture below shows the location of the screws to remove



1.b. Remove the upper part of the center console





1.c. Remove the console rear












2. Run the power connector + interconnect cable + remote control cable from the subwoofer to the head unit, under the carpet, then under the centre console














3. Connect the power connector to the 12V power socket







4. Connect the subwoofer cable bundle to the headunit







5. Fix and glue the remote control in the centre armrest







































B www.focal.com







